Temperature Monitoring Devices -Logtag

Install the software –this icon would be there on the desktop. Double click that beore connecting the logtag to the computer.

This window will apper on the computer screen.



Connect logtag interface to the USB port of the computer

Place the logtag in the interface-when connecting, both logtag logos should face the same way.

This will apper on the computer screen

Latest temperature chart would apper on the screen.



Save the temperature chart by going to the file and by cliclking save as button/take a printout by clicking the print button



Restart the logtag by clicking the 'logtag' icon




LogTag
Action List
1. Welcome and general instructions
2. Locate LogTag(s), download and save relevant data
3. Configure LogTag(s) for next use
4. Prepare LogTag(s) for next use
Welcome to LogTag products.
This process will take you through a series of steps that will allow you to retrieve any information that exists within a LogTag product, for example recorded temperature sensor readings, and change the configuration of a LogTag product ready for its next use.
Please ensure the following are correct:
1. LogTag Interface is plugged into computer communications port.
2. LogTag logger is completely inserted into the LogTag Interface.
Do not show me this information again
< Back
Next >
Cancel
Help

Press next


LogTag
Action List
1. Welcome and general instructions
2. Locate LogTag(s), download and save relevant data
3. Configure LogTag(s) for next use
4. Prepare LogTag(s) for next use
The software will locate the LogTag products for you, download the relevant information and save the information to disk. Please wait while this process completes. When completed you can press the Next button to configure the LogTag products for their next use, or press the Finish to exit this process.
Location
Interface Model
LogTag ID
Readings
USB
LTI/USB
0004310317
455
USB
LTI/USB
Not found
COM1
LTI/RS232
000B110337
7906
COM2
Not found
100%
Again
< Back
Next >
Close
Help

Press next

Log Tag Settings

Change the Place & date here . You have to type the name only once. Afterwards, change only the date (e.g. MOH office-Lunugamvehera 11.06.2015)



Press next



Once it is 100%, take out the logtag

Hold this button to start the data lodger-both alert and OK buttons will light up when starting

How to change Fahrenheit to Celsius

Edit → Options → General Settings → Celcius




LogTag Analyzer 2.3 Build 30 - CR 2 -03 5-5-2015, Finished 5-18-2015
File Edit LogTag Window Help
Copy Ctrl+C
Zoom Out
Real Time
Elapsed Time
Zoom to Marks
Previous group of Marks
Next group of Marks
Options...
1056001554 - EPID CR no.2 05.05.2015 -3
Readings (°C)
Display clock time zone
Report Chart Data Summary Day Summary


LogTag Analyzer 2.3 Build 30 - CR 2 -03 5-5-2015, Finished 5-18-2015
File Edit LogTag Window Help
CR 2 -03 5-5-2015, Finished 5-18-2015
1056001554 - EPID CR no.2 05.05.2015 -3
Options
General Settings
Summary Statistics
Chart Statistics
Charts
Automation
File and Folder Settings
Exports and Reports
Date and Time
Communication Ports
User Server
Updates
Configuration Logs
Show temperatures in
Fahrenheit (°F)
Celsius (°C)
Fahrenheit (°F)
Kelvin (K)
Default time interval to dis
All readings
Use Font
9 pt. MS Shell Dlg
Font...
Language
English (US)
OK
Cancel
Help
Display clock time zone
Report Chart Data Summary


LogTag Analyzer 2.3 Build 30 - CR 2 -03 5-5-2015, Finished 5-18-2015
File Edit LogTag Window Help
CR 2 -03 5-5-2015, Finished 5-18-2015
1056001554 - EPID CR no.2 05.05.2015 -3
Options
General Settings
Summary Statistics
Chart Statistics
Charts
Automation
File and Folder Settings
Exports and Reports
Date and Time
Communication Ports
User Server
Updates
Configuration Logs
Show temperatures in
Celsius (°C)
Fahrenheit (°F)
Kelvin (K)
Default time interval to dis
All readings
Use Font
9 pt. MS Shell Dlg
Font...
Language
English (US)
OK
Cancel
Help
Report
Chart
Data
Summary
Display clock time zone


Options
General Settings
Summary Statistics
Chart Statistics
Charts
Automation
File and Folder Settings
Exports and Reports
Date and Time
Communication Ports
User Server
Updates
Configuration Reports
Show temperatures in
Celsius (°C)
Use Font
9 pt. MS Shell Dlg
Font...
Language
English (US)
OK
Cancel
Help